

0x08872a60 [0,0]

Contents: [Dobrica Pavlinu's random unstructured stuff]

- Dobrica Pavlinu's random unstructured stuff (Links)
- Dobrica Pavlinu's random unstructured stuff (Installation)
 - ◆ Dobrica Pavlinu's random unstructured stuff (Make bootable usb stick)
 - ◆ Dobrica Pavlinu's random unstructured stuff (Bios boot disk)
 - ◆ Dobrica Pavlinu's random unstructured stuff (Boot from usb stick)

Links

- <http://virtuallyshocking.com/2008/12/20/building-android-for-the-asus-eeepc-701/>

Installation

Make bootable usb stick

```
root@llin:~# dd if=/mnt/usb/eee/eeeDroid_2008-12-20_1843Z.img of=/dev/sdc
797784+0 records in
797784+0 records out
408465408 bytes (408 MB) copied, 133.768 s, 3.1 MB/s
```

Bios boot disk

- press **F2** to enter bios
- from **Boot** menu reorder disks using **+** and **-**:
- under **Advanced** menu disable **Onboard CardReader**

```
HDD:SM-SILICONMOTI
Removable Dev.
```

- press **F10** to save settings

Boot from usb stick

- press **ESC** to bring boot menu and select **USB:SMI USB DISK**