

<https://tasmota.github.io/docs/devices/Sonoff-T1/>

Configuration > Configure Module > Sonoff T1 3CH

immediately after flashing Tasmota (so it won't reset when powered from adapter):

SetOption13 1

mapping:

<https://github.com/arendst/Tasmota/blob/a466c5abf33386c3dda34696e11ae975c7ac6649/tasmota/tasmota.ino>

```
{                                // SONOFF_T13 - Sonoff T1 3CH (ESP8285)
    GPIO8_KEY1,                  // GPIO00 Button 1
    GPIO8_USER,                  // GPIO01 Serial RXD and Optional sensor
    GPIO8_USER,                  // GPIO02 Optional Sensor (J3 Pin 5)
    GPIO8_USER,                  // GPIO03 Serial TXD and Optional sensor
    GPIO8_REL3,                  // GPIO04 Blue Led and Relay 3 (0 = Off, 1 = On)
    GPIO8_REL2,                  // GPIO05 Blue Led and Relay 2 (0 = Off, 1 = On)
    0,                           // GPIO06 (SD_CLK Flash)
    0,                           // GPIO07 (SD_DATA0 Flash QIO/DIO/DOUT)
    0,                           // GPIO08 (SD_DATA1 Flash QIO/DIO/DOUT)
    GPIO8_KEY2,                  // GPIO09 Button 2
    GPIO8_KEY3,                  // GPIO10 Button 3
    0,                           // GPIO11 (SD_CMD Flash)
    GPIO8_REL1,                  // GPIO12 Blue Led and Relay 1 (0 = Off, 1 = On)
    GPIO8_LED1_INV,              // GPIO13 Blue Led (0 = On, 1 = Off) - Link and Power status
    0, 0, 0, 0
},
```